	Key word	Page
A	Advantages of the options	38
	Axle plate alignment	64
	Axle plates	46
	Axle ring - One-piece / Quick-change	98, 104
	Axle types	24
B	Bolt/tool info	124
	Brake disc - replacement	60, 91
	Brake discs / rotors	37
	Break-in period	6
C	Cable routing via the brake boss - Internal gear mech	76
	Cable routing via the chainstay - External gear mech	80
	Cable routing via the chainstay - Internal gear mech	79
	Cable routing via the top tube - External gear mech	83
	Carbon handlebars	48
	Chain guide - DH (accessory for downhill)	45, 58
	Chain guide - CC	71
	Chain tensioner - DH (accessory for downhill)	45, 68, 69
	Chain tensioner - mounting	70
	Chain tensioner spring - changing	109
	Chainguard enclosed	48
	Chainring - two chainrings	45, 47
	Cleaning the Rohloff SPEEDHUB 500/14	7
	Colors	33
	Comparison - Derailleur gears and Rohloff SPEEDHUB 500/14	21
	Comparison to derailleur gears	22
	Components that we recommend	45
	Cranks, Crankset	45, 57
D	Distance travelled per crank revolution (20", 26" and 28")	20
E	Emergency repairs	10
	External gear mech - grub screw	129
	External gear mech - mounting	32, 93
	External gear mech - OEM / OEM2 / long torque arm	63
F	Failure Diagnosis	119
	Filling with oil	84
	Frame mounted gear box	47
	Frame types - OEM / OEM2 / long torque arm	27-29
G	Gear display	83
	Gear mech - replacement	92
	Gear unit - installation - removal	112, 111
	Grub screw of the External gear mech	129
	Guarantee information	1, 128
H	Hub cable - replacement	97
	Hub seal - replacement	114
I	Index	132
	Inner rim diameter - calculating	44
	Internal gear mech	31
	Internal gear mech - via brake boss / via chainstay	61, 62
L	Long torque arm	56
M	Maintenance and care	7, 8, 89
	Mechanical efficiency - comparsion	18
	Model codes - explanation	33
	Model variations	39

	Key word	Page
N	Noises	6
	Notices	130
O	OEM axle plate	67
	OEM2 - mounting with a support bolt / SPEEDBONE	59
	OEM2 axle plate	67
	Oil change	7, 87
	One-piece axle ring - removal	92
	Options	38
P	Package contents - checking	51
	Particular components	45, 46, 47
	Pushing the bike	6
Q	Quick-change axle ring - removal	92
R	Racing bike / drop handlebars	46
	Reference to Serial N°	128
	Removal of the wheel from the frame	13
	Replacing the gear unit	92
	Reversing / Replacing of the sprocket	90
	Riding noises	6
	Rims	46
	Rubber grip - replacement	110
S	Safety information	3
	Schlumpf Speed-drive, High Speed-drive	47
	Securing to the frame	23-30
	Serial N°- Pointers	128
	Service procedures	96
	Shifter - mounting	73
	Shifter cables	75
	Shifting gears	5
	Small parts bag - checking the contents	53
	Small wheels	47
	Smallest permitted sprocket ratios	19
	Special applications	47, 48
	SPEEDBONE	46
	Spoke length - calculating	42, 43
	Spokes	46
	Sprocket ratios - smallest	19
	Sprocket reversing/replacement	90
	Sprockets	45
	Stand - axle mounted	47
T	Tandem use	47
	Technical data	17, 127
	Tools and Bolts / Tools for the tour	124 , 9
	Torque securing	25
	Tour info	9
	Trailer use	47
	Transport - Info for the tour	9
	Trouble shooting	119
	Twist shifter - mounting	73
W	Warranty information	1, 128
	Wearable parts	6
	Weight comparison	18
	Wheel installation	14

Modular system	**23**
Mounting (CC / TS versions) with a long torque arm	**65, 66**
Mounting necessities OEM2	**30**
Mounting processes	**49**

Wheel lacing for rims with a European spoke hole pattern	**125**
Wheel lacing for rims with a French spoke hole pattern	**126**
Wheel removal (internal, external gear mech)	**11**
Wheel stability	**41**
Wheel lacing	**55**

KOPIE